



## Assembly Instructions - Front Basket








### Tools required



- Metric Allen key set 2mm to 5mm
- 8 & 10mm keys
- Plastic ties (tie-wrap)

### Hardware required

- One M6x16mm wide-head screw
- One M6 nut with nylon insert

	Unscrew the fork-mounted headlight from the front fender bracket and carefully set aside.
	Tighten the front mudguard fixing screw firmly, ensuring maximum clearance for the tire.
	Loosen the four fixing screws on the bike's head tube.
	Position the front basket on the bike's head tube, aligning the mounting holes. Tighten the fixing screws.
	Unroll the spiral sheath portion covering the wire couette that runs into the left side of the bike from where the headlight power cable enters it.
	Unscrew the four screws securing the basket's wooden base and remove it from the basket to expose the headlight attachment bracket integrated into the basket structure. Set aside the wooden base and screws.

	<p>Unscrew the cable guide fixing screw on the left-hand side of the bike and set aside. Carefully pull out the cable guide to gain access to the cable comforter inside the bike frame.</p>
	<p>Identify the headlight power cable, then carefully pull to obtain the additional length required so that the headlight can be attached to the basket bracket without being overstretched or damaged.</p>
	<p>Slightly loosen the headlight bracket fixing bolt and rotate it backwards by approximately 45 degrees.</p>
	<p>Align and position the headlight support on the attachment bracket under the basket structure.</p>
	<p>Securely fasten the headlight bracket to the basket mounting bracket using an M6 bolt (we recommend using a nut with a nylon insert to prevent the bolt from loosening with vibration).</p>
	<p>Adjust the angle of the headlight so that it points slightly towards the ground, so that it illuminates the ground in front of the bike wheel, then tighten the headlight bracket fixing bolt firmly.</p>

	<p>Secure the headlight power cable to the basket structure with plastic ties to avoid contact with the front wheel.</p>
	<p>Wrap the spiral sheath around the cable comforter up to the frame, then carefully screw the cable guide back into place.</p>
	<p>Secure the wooden base of the basket with the fixing screws.</p>